

### **Installation Instructions:**

Film Wall can be applied to various types of surfaces using a wet application method. Before applying the product, you must make sure that the surface, which the material will be applied to, is prepared properly.

#### ***Surface Preparation:***

- First wash the surface that the material will be applied to with an ammonia solution or alcohol; rinse, and allow drying before installation.
- Fill any cracks, gouges, or nicks with an automotive body filler.
- After the area has been filled, sand smooth. We recommend sealing with an acrylic based sealant for absorptive surfaces.

#### ***Film Preparation:***

- Film should be allowed to acclimate to room temperature for easy handling. It is recommended that room temperature be above 50°F when working with film.
- Precut the film to the size you require, leaving a few extra inches for trimming the material.
- When handling, be careful not to crease or bend the material.

### **Application of dry erase film:**

- Tools: squeegee, sharp knife, spray bottle, water, and dish detergent
- First prepare surface and film as described above.
- Draw both a vertical plumb line and a horizontal level line with a pencil to use as a reference line to align the film. (Note: When covering a large area, two installers are recommended.)
- Wet surface that film will be applied to with soapy water solution. (Soapy water solution consists of a ½ cap of dish detergent to 2 gallons of water.)
- Peel about 12” of the release liner back, and spray both sides of the film.
- Position the edge of the film on the horizontal and plumb lines.
- Use the squeegee in a downward and outward motion to remove all air and water pockets and to obtain a good adhesion.
- Continue to pull back the film, and apply water to both sides of the film; continue to use the squeegee to smooth out the surface and to remove the water.
- Trim the excess material along the edges.
- Wipe down the surface with clean water, and dry with a towel. (Note: This step is not necessary if a protective peel sheet is included on the material.)
- Allow the material to set for a couple hours before using. If you can, it is best to let the material sit overnight before using.

### **Care before using writing surface:**

Clean the surface completely with a non-abrasive cleaner, like a glass cleaner, and a soft cloth. Once cleaned, wipe with a damp rag, and dry with a soft cloth. The purpose of this is to ensure that there is no cleaning residue left on the writing surface.

#### *Disclaimers:*

*Although this product is designed to be removable, we cannot guarantee that it will not pull away some of the paint from the original surface, as well as paper off of paper-surfaced products, due to the low cohesive strength. We recommend that you test a small piece on a similar surface, if possible, before application.*